


VON DUPRIN

Installation Instructions

EPT2 & EPT10 Filler Kit

This kit fills the gap created on both sides of the EPT2 or EPT10 when installed in a prep created for an EPT218 or EPT1024.

PARTS LIST: Adhesive backed plastic strip  (4)

INSTALLATION:

