



SEX BOLT APP. (METAL DOOR)	SEX BOLT APP. (WOOD DOOR)
1/4" DIA 2 HOLES INSIDE FACE ONLY	DRILL 13/32" DIA THRU 2 HOLES
13/32" DIA 2 HOLES OUTSIDE FACE ONLY	

NOTE:
#25 DRILL, #10-24 TAP (2 PLACES)
WHEN USED WITH 990DT, 991DT,
992DT, 230DT, 696DT, OR 697DT TRIM
(METAL DOOR) - THIS SIDE ONLY

TRIM INSTALLATION SCHEDULE		
INSTALLATION	STILE SIZE	BACKSET
④ SINGLE DOOR 1/2" STOP & BACK TO BACK WITH 386DT, 337DT OR 696/697DT TRIM ON SINGLE DOOR 1/2" STOP	1 3/4" - 3"	1 5/16"
④ SINGLE DOOR 5/8" STOP & BACK TO BACK WITH 386DT, 337DT OR 696/697DT TRIM ON SINGLE DOOR 5/8" STOP	1 7/8" - 3"	1 7/16"
④ PAIR OF DOORS WITHOUT MULLION & BACK TO BACK WITH 386DT, 337DT OR 696/697DT TRIM ON PAIR OF DOORS WITHOUT MULLION	1 3/4" - 3"	1 5/16"
SINGLE DOOR PAIR OF DOORS WITHOUT MULLION BACK TO BACK WITH 990DT, 991DT, 992DT, OR 230DT	3" - FLUSH	1/2 OF STILE

LHR SHOWN
RHR OPPOSITE

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

330, 350, TBSK330, & TBSK350
PUSH BAR TRIM



TEMPLATE NUMBER:

20030_4

DATE:

06/23/03