



DOUBLE DOOR APPLICATION SHOWN.
 FOR SINGLE DOOR APPLICATION USE
 APPROPRIATE HANDING AS SHOWN.

NOTES: 1. SEE DEVICE TEMPLATE FOR
 LOCATION OF LATCH BOLT.

471-U STRIKE FOR 5547
 HOLLOW METAL FRAME PREPARATION



NOTE: SEE MASTER SHEET NO. 10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: 30013_3

DATE: 7-29-98