



- NOTE: 1. FOR DEVICE FUNCTIONS SEE APPROPRIATE DEVICE TEMPLATES.
 2. SEE DEVICE TEMPLATE FOR MOUNTING HOLE LOCATIONS.
 3. A COORDINATOR MUST BE USED ON THE INACTIVE DOOR.

1609 STRIKE APPLICATION
 FOR 2227 VERTICAL ROD & 22
 RIM DEVICES (PANIC DEVICE ONLY)



NOTE: SEE MASTER SHEET NO. 10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: 30244_3

DATE: 9-29-98