



TRIM INSTALLATION SCHEDULE		
INSTALLATION	STILE SIZE	BACKSET
SINGLE DOOR 1/2" STOP & BACK TO BACK WITH 337DT OR 696/697DT TRIM ON SINGLE DOOR 1/2" STOP	1 3/4"-3"	1 5/16"
SINGLE DOOR 5/8" STOP & BACK TO BACK WITH 337DT OR 696/697DT TRIM ON SINGLE DOOR 5/8" STOP	1 7/8"-3"	1 7/16"
PAIR OF DOORS WITHOUT MULLION & BACK TO BACK WITH 337DT OR 696/697DT TRIM ON PAIR OF DOORS WITHOUT MULLION	1 3/4"-3"	1 5/16"
SINGLE DOOR PAIR OF DOORS WITHOUT MULLION BACK TO BACK WITH 990DT, 991DT, 992DT, OR 230DT	3"-FLUSH	1/2 OF STILE

LHR SHOWN
RHR OPPOSITE

330, 350, TBSK330, & TBSK350
PUSH BAR TRIM



NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: 20030_3

DATE: 8-18-98