



NOTES:

1. FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE TRIM TEMPLATE
2. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR,
3. SEE TEMPLATE #30038 IN HOLLOW METAL TEMPLATE BOOK FOR 338 STRIKE.
- (11) 4. DOOR EDGING SHOULD BE INSTALLED AFTER DEVICE INSTALLATION.

LHR APPLICATION SHOWN,
RHR APPLICATION OPPOSITE

5547WDC & 5547WDC-F SERIES
VERTICAL ROD DEVICES



NOTE: SEE MASTER SHEET NO. 10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10080_11

DATE:
3-13-01