



WIRING FOR E7500 & SS7500 LOCKS:
GO THRU DOOR AND NOT DEVICE.
MINIMUM RACEWAY CLEARANCE IS 1/4"

LHR SHOWN
RHR OPPOSITE

NOTE: MOUNTING HOLES TO BE PREPARED
AT INSTALLATION ON DOOR
FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED,
SEE ADDITIONAL TRIM TEMPLATE

8875/8875-F MORTISE LOCK DEVICE (WOOD DOOR)



NOTES:

TEMPLATE NUMBER: W10179_3

DATE: 6/16/98